

Edging. Walls. Paving.

Landscaping Product Guide



Contents

EDGING & WALLS

- 6 Vivid Edge™
- 8 Easy Edge
- 10 BoldStone™
- 12 Classic Wall®
- 14 TrendStone®

PAVING

- 18 LeMode Paving Range
- 19 LedaPAVE
- 20 CentroPAVE
- 21 SierraPAVE
- 23 AdraPAVE

HINTS & HOW TO'S

- 30 Vivid Edge Estimation & Installation Guide
- 30 Easy Edge Estimation & Installation Guide
- 31 BoldStone Estimation & Installation Guide
- 31 Classic Wall Estimation & Installation Guide
- 32 TrendStone Estimation & Installation Guide
- 33 Paving Estimation & Installation Guide
- 34 Paving & Retaining Walls Maintenance

Welcome to Apex Masonry



THE QUEENSLAND LOCALS

Since 1979, Apex Masonry has been producing locally made blocks, pavers and bricks from a mix of high-grade, unique materials sourced from local quarries.

For almost 40 years, our building and landscaping products have set a sound and resilient foundation for residential homes, multi-residential apartments, commercial developments, public spaces and civil projects across south-east Queensland.

EMBRACING INNOVATION

Over the years, our design team and production engineers have achieved a series of practical and clever Australian firsts for our industry.

We listen to our customers and we respond to every day challenges - with designs that make our blocks, pavers and bricks a little easier to handle and lay for our customers.

ENVIRONMENTALLY FRIENDLY


Apex Masonry takes a proactive approach to investing in sustainable solutions for the built environment.

Where possible, our products are manufactured from recycled waste to reduce environmental impact, improve energy efficiency and generate a greener, more sustainable future for our industry.



Our Customer Service Promise

- 1 Respond to all customer enquiries within 30 minutes during business hours.
- 2 Replace any damaged or broken products.
- 3 Always available to answer your calls, even outside business hours – **24 hours / 7 days.**
- 4 Free delivery on all orders over minimum quantity.
- 5 Next day deliveries to the following regions: Brisbane, Sunshine Coast, Gold Coast, Hervey Bay, Maryborough, Bundaberg and Gympie.



Edging & Walls

Elegant. Regal. Stylish.

Vivid Edge

Easy Edge

BoldStone

Classic Wall

TrendStone

Vivid Edge™

Garden Edging

The decorative & vivid garden edging solution.



Vivid Edge™ Gold Blend



Vivid Edge Gold Blend




Vivid Edge™ Slate

Apex Masonry's Vivid Edge™ garden edging adds a decorative and distinct touch to a landscape or garden. Vivid Edge™ is a concrete edging designed for longevity and durability.

Vivid Edge's™ textured design and faux joint creates a naturally irregular finish. The bevelled ends allow for straight or curved instalment, enabling it to be used for garden edging, mowing strips and pathway borders.


COLOURS



Slate

Gold Blend


Ironstone



Straight Wall

Curved Edge

SPECIFICATIONS




Vivid Edge™ Unit


300 / 280 x 80 x 80mm

No. per Pallet: 320

No. per Lm: 3.5



Garden Edging



Stacked Garden Wall

FEATURES

- › Versatile Garden Edging
- › 2 sided stack and go edging
- › Self capping
- › Build curved or straight edges
- › Great for free form edges with minimal cuts
- › Only 1 component

Max. Wall Height (mm)	160 - 2 units
Circle - Min. External Diameter (mm)	2180 - 23 units
Suitable For:	
Straight & Curved Edges	✓
Tree Surrounds	✓
Garden & Lawn Edging	✓
Pathways	✓

Easy Edge

Garden Brick Edging

The WEED FREE garden edging solution.



Easy Edge Charcoal



Easy Edge Ivory




Easy Edge Pebble

Say goodbye to weeding between your garden brick edging with Apex Masonry's Easy Edge.

Our unique design closes gaps to obstruct weeds from growing between bricks. Quick and easy to install, Easy Edge can be laid along straight or curved walls, for garden borders, tree surrounds or to simply separate your garden from the lawn.

COLOURS




Canyon

Charcoal

Pebble

Ivory

SPECIFICATIONS




Easy Edge Unit

135 / 90 x 140 / 90mm
 No. per Pallet: 480
 No. per Lm: 9
 Weight per Unit: 3.1kg


Straight Wall



Curved Wall



Garden Edging



Small Garden Wall

Max. Wall Height (mm)	180
Circle - Min. External Diameter (mm)	820 - 19 units
Suitable For:	
Straight & Curved Walls	✓
Tree Surrounds	✓
Garden & Lawn Edging	✓
Garden Walls	✓

FEATURES

- › Easy to handle
- › Natural Stone look
- › Innovative designs
- › No gaps - WEED FREE
- › Quick and easy to install
- › Only 1 component

BoldStone™

Garden Wall

The Bold garden wall edging solution.



BoldStone™ Gold Blend



BoldStone™ Pebble



BoldStone™ Slate (Firepit)

Apex Masonry's BoldStone™ garden wall delivers a mini boulder look giving a unique and flexible solution for straight or curved walls.

The flexibility of BoldStone™ as a garden wall makes it an instant favourite. The tumble process during manufacturing results in a natural stone appearance. With its 2-sided profile, the BoldStone™ garden wall allows for a wide range of applications and design options.


COLOURS



Slate

Gold Blend

Pebble



Straight Wall


Curved Wall

SPECIFICATIONS



BoldStone™ Unit

293 / 200 x 185 x 100mm
 No. per Pallet: 144
 No. per Lm: 4
 No. Per m²: 40
 Weight per Unit: 8.6kg



Max. Wall Height (mm)	500
Circle - Min. External Diameter (mm)	1092 - 12 units
Suitable For:	
Straight & Curved Walls	✓
Tree Surrounds	✓
Garden & Lawn Edging	✓
Garden Walls	✓
Planter Boxes	✓

FEATURES

- › Garden wall or planter boxes
- › 2 sided stack and go wall
- › Self capping
- › Build curved or straight walls
- › Great for free form walls with minimal cuts
- › Only 1 component

Classic Wall®

Retaining Wall System


A simple retaining wall system with a classic appearance.



Apex Masonry's Classic Wall® Retaining Wall system delivers a simple, functional and flexible solution for straight or curved walls.

For accurate and continuous angling of the wall, every block is manufactured with a small lip for locating the course. Made solid for strength and durability, Classic Wall® is designed to withstand Australia's harsh and ever changing climate conditions.

COLOURS




Canyon Charcoal Pebble Ivory Gold Blend

FEATURES


- Natural Stone look
- Quick & easy to install
- Split on 3 front faces giving a uniform appearance
- Only 1 component
- Small lip at rear for easy stacking
- Manufactured & Tested to Australian Standards

SPECIFICATIONS



Classic Wall® Unit

255 x 200 x 125mm
 No. Per Pallet: 125
 No. Per m²: 31.4
 No. Per Lm: 3.92
 Weight per Unit: 11.7kg



Max. Wall Height (mm) <small>Greater heights available with engineering</small>	1000
Circle - Min. External Diameter (mm)	1350 - 15 full units
Suitable For:	
Retaining Walls	✓
Straight & Curved Walls	✓
Tree Surrounds	✓
Planter Boxes	✓
Garden Walls & Edges	✓

TrendStone®

Retaining Wall System


Australia's only retaining wall system with uninterrupted bevelling.



Designed and developed by Apex Masonry, our TrendStone® Retaining Wall system offers Australia's only range of standard and universal corner blocks with four bevelled edges on all block faces.

To guarantee our walls stay in bond, Apex Masonry supplies every block with an indicator for laying consistency and locating keys to ensure blocks remain in bond around curves.


COLOURS - STANDARD RANGE



Charcoal

Pebble

COLOURS - DESIGNER RANGE



Fraser Sand

Fraser Coral

Ivory

SPECIFICATIONS



TrendStone® Wall Unit

400 x 245 x 200mm
No. Per Pallet: 78
No. Per m²: 12.5
Weight per Unit: 22.5kg



TrendStone® Corner

390 x 190 x 200mm
No. Per Pallet: 75
Weight per Unit: 21.3kg



TrendStone® Cap

400 x 255 x 65mm
No. Per Pallet: 120
No. Per Lm: 2.5
Weight per Unit: 14.5kg


FEATURES

- Natural Stone look
- Universal corner block – no left & right corners
- Only 3 components
- Quick & easy to install
- Vertical faced
- Always remains in bond
- Bevels on all edges
- Manufactured & Tested to Australian Standards

Max. Wall Height (mm)	865
With Road Base Footing	1065
With Concrete Footing	3065
With Specific Engineering	

Circle - Min. External Diameter (mm)	2330
	- 16 units

Suitable For:	
Retaining Walls	✓
Straight & Curved Walls	✓
Planter Boxes	✓
Garden Walls & Edges	✓
Steps	✓
Courtyards	✓




Notes:

Curves - For convex curved walls simply knock the back fin off the block with a hammer. Specific engineering must be drawn up if any site conditions are outside the standard.



TrendStone® & LedaPAVE Ivory



Paving

Smart. Precise. Versatile.

LeMode Paving Range

LedaPAVE

CentroPAVE

SierraPAVE

AdraPAVE

LeMode® Paving Range

The versatile DIY paver.

Apex Masonry's range of LeMode® bevelled pavers offer affordable quality and style for courtyards, entertaining areas, pathways, patios and pool surrounds.


The versatile DIY paver features a 'Smart Bevel' on all edges. The bevelled edge improves the durability of the paver, preventing chipping on the side of the paver.

With sizing in increments of 100mm, LeMode® pavers deliver the ability to mix and match shapes and dimensions across the entire range.

FEATURES

- › Compressive Strength Rated
- › 40mm thick
- › Smart bevel
- › Bevels on four edges
- › Range of dimensions and colours
- › Use in a combination to create patterns


SIZES



LedaPAVE

Page 19


400 x 400 x 40mm
No. per m²: 6.25



CentroPAVE®

Page 20

300 x 300 x 40mm
No. per m²: 11.1



SierraPAVE®

Page 21

400 x 200 x 40mm
No. per m²: 12.5



AdraPAVE

Page 22

200 x 100 x 40mm
No. per m²: 50



LedaPAVE Canyon & SierraPAVE® Ivory



LeMode® French Paving Pattern Pebble

LeMode®

LedaPAVE




LedaPAVE Ivory



LedaPAVE Fraser Coral

Classic large format paver – Ideal for large spaces and stepping stones.

COLOURS



Canyon

Charcoal

Fraser Coral

Ivory


Pebble

Suitable For:


- Courtyards
- Entertaining Areas
- Pathways
- Patios
- Pool Surrounds
- Stepping Stones



PATTERNS



SPECIFICATIONS



LedaPAVE

400 x 400 x 40mm
No. per pallet: 117
No. per m²: 6.25
Weight per Unit: 13.2kg

LeMode®

CentroPAVE®

LeMode®

SierraPAVE®



CentroPAVE® Charcoal



CentroPAVE® Pebble



SierraPAVE® Ivory




SierraPAVE® Charcoal with bevel laid down

Large format budget paver – Affordable alternative for large format pavers.


For distinctive patterns – Versatile for creating herringbone and basket weave patterns.

COLOURS



Canyon Charcoal Ivory Pebble

COLOURS




Canyon Charcoal Ivory Pebble


Suitable For:

- Courtyards ✓
- Entertaining Areas ✓
- Pathways ✓
- Patios ✓
- Pool Surrounds ✓
- Stepping Stones ✓

PATTERNS




SPECIFICATIONS



CentroPAVE®
 300 x 300 x 40mm
 No. per pallet: 192
 No. per m²: 11.1
 Weight per Unit: 7.7kg

PATTERNS



SPECIFICATIONS



SierraPAVE®
 400 x 200 x 40mm
 No. per pallet: 252
 No. per m²: 12.5
 Weight per Unit: 6.9kg



AdraPAVE Canyon



AdraPAVE Pebble with Ivory border


The LeMode® French Paving Design combines each of the pavers in the LeMode® Paving Range to create this unique pattern. If you're after a truly designer landscape...the LeMode® French Paving Design is the way to go.

For more information go to www.apexmasonry.com.au/french




For paving, borders or edging – Small format paver that lends itself to a wide range of patterns.

COLOURS



Canyon Charcoal Ivory Pebble

PATTERNS



SPECIFICATIONS




AdraPAVE
200 x 100 x 40mm
No. per pallet: 600
No. per m²: 50
Weight per Unit: 1.7kg

Suitable For:

- Mower Strip ✓
- Garden Edging ✓
- Courtyards ✓
- Entertaining Areas ✓
- Pathways ✓
- Patios ✓



LedaPAVE Ivory & AdraPAVE Ivory



Hints & How-to's

Plan. Install. Maintain.

- Vivid Edge Estimation & Installation Guide
- Easy Edge Estimation & Installation Guide
- BoldStone Estimation & Installation Guide
- Classic Wall Estimation & Installation Guide
- TrendStone Estimation & Installation Guide
- Paving Estimation & Installation Guide
- Paving & Retaining Walls Maintenance

Vivid Edge™ & Easy Edge Estimation & Installation Guide

Vivid Edge™

Estimate Quantity Required

1. Measure the length (L) of the wall.
2. To calculate the number of units required, multiply the (L) x number of units per lineal metre (3.5/Lm).
3. Multiply the number of units per course by how many course/s high the wall will be.
4. Order an extra 5% to allow for cuts.

Installation Guide

STEP 1 - PREPARING THE BASE

Mark out the ground and dig a trench 150-200mm wide and 50-75mm deep. Fill the trench with crusher dust or bedding sand and compact it. Optional: mix crusher dust or bedding sand with cement 6:1 to stabilise. Screed to a true level. *

STEP 2 - LAYING THE FIRST COURSE

Place the garden edging unit onto prepared base. Make sure 10-20mm of first block is below finished ground level. **

STEP 3 - PLACING ADDITIONAL COURSE

If laying more than one course: Continue laying subsequent courses following the same procedure as the first course. Place each course in a running bond with the course below (i.e., with the vertical joints from the first-course units halfway along with the second-course units). It is recommended to use liquid nails/masonry adhesive to glue each course together.

Easy Edge

Estimate Quantity Required

1. Measure the perimeter (P) of the area to be edged.
2. To calculate the number of units, multiply the P x number of units per lineal metre (9/Lm).
3. If a double height edge is being created, double the number of units.
4. Order an extra 5% to allow for cuts.

Installation Guide

STEP 1 - DESIGN THE EDGE

Mark out the design on the ground in the location of the edge.

STEP 2 - PREPARE THE BASE

Dig a small trench just deep enough to create a levelling pad for the edge. Fill with crushed rock or concrete and level.

STEP 3 - LAYING THE EDGE

Place Easy Edge bricks onto base, alternating the bricks to create straight edges or laying consecutive bricks the same way to create curves.

STEP 4 - PLACING ADDITIONAL COURSE

Lay the second course of Easy Edge if desired. Secure using masonry adhesive.

Installation Hints

- * For additional strength, fill trench with concrete. Screed to a true level, starting from the lowest point if wall is stepping up. Don't make the concrete mix too wet otherwise the blocks will sink into the mix.
- ** It is essential that this first course of units is placed accurately to string line and levelled using a spirit level.
- *** Make sure that the drainage pipe has roughly a 1 in 100 fall (1cm drop over 1m length of wall).

BoldStone™ & Classic Wall® Estimation & Installation Guide

BoldStone™ Garden Wall

Estimate Quantity Required

1. Measure the length (L) of the wall.
2. To calculate the number of units required, multiply the (L) x number of units per lineal metre (4/Lm).
3. Multiply the number of units per course by how many course/s high the wall will be.
4. Order an extra 5% to allow for cuts.

Installation Guide

STEP 1 - PREPARING THE BASE

Mark out the ground and dig a trench 250mm wide and 50-75mm deep. Fill the trench with crusher dust or bedding sand and compact it. Optional: mix crusher dust or bedding sand with cement 6:1 to stabilise. Screed to a true level. *

STEP 2 - LAYING THE FIRST COURSE

Place the garden edging unit onto the prepared base. Make sure 10-20mm of the first block is below finished ground level. **

STEP 3 - PLACING THE DRAIN

If laying more than one course: Continue laying subsequent courses following the same procedure as the first course. Place each course in a running bond with the course below (i.e., with the vertical joints from the first-course units halfway along with the second-course units). It is recommended to use liquid nails/masonry adhesive to glue each course together.

Classic Wall®

Estimate Quantity Required

1. Measure the length (L) and height (H) of the wall.
2. Multiply the L x H to work out the square metreage area (m²) of the wall.
3. Multiply the m² of the wall by the number of units in a m² (31.4/m²).
4. Order an extra 5% to allow for cuts.

Installation Guide

STEP 1 - PREPARING THE BASE

Mark out ground and dig a trench 500mm wide and 150mm deep. Fill trench with road base and compact. Cover road base with 25mm sharp sand or crushed blue metal. Screed to a true level.*

STEP 2 - LAYING THE FIRST COURSE

Place wall unit onto prepared base. Make sure 50mm of first block is below finished ground level.**

STEP 3 - PLACING THE DRAIN

Place agricultural drainage pipe (Ag-pipe) behind first course of wall on a bed of drainage material. Outlet the drain through wall at every low point, every 20 metres and around ends of wall.***

STEP 4 - PLACING ADDITIONAL COURSES

Continue laying subsequent courses following same procedure as first course. Place each course in running bond with course below (i.e. with the vertical joints from the first course units halfway along second course units).

STEP 5 - BACKFILLING

Back fill behind the wall using 10-20mm drainage material (10-20mm gravel), maintaining a high compaction rate.

STEP 6 - LAYING FINAL COURSE

Once backfilling and cleaning is complete, fix final course of Classic Wall® into place using masonry adhesive.

STEP 7 - SURFACE DRAINAGE LAYER

Place 100-150mm of clay impermeable layer (or similar) on top of the wall fill to divert water away from the face of the wall.

TrendStone®

Estimate Quantity Required

1. Measure the length (L) and height (H) of the wall.
2. To calculate the number of wall units, multiply the L x H x number of units per m² (12.5/m²).
3. For capping units, multiply L x the number of units per lineal metre (2.5/Lm).
4. For corner units, add up number of internal & external corners required and multiply it by the number of courses high the wall is.
5. Order an extra 5% of all items to allow for cuts.

Notes:

Core fill Requirements - 0.85m³ of aggregate or No Fines concrete fills 100 blocks. 0.106m³ of aggregate or No Fines Concrete fills 1m² blocks.

Installation Guide

STEP 1 - PREPARING THE BASE

Mark out the ground using stakes and a string line or by marking a line on the ground with spray paint. Dig a trench approximately 600mm wide and no less than 150mm deep.

For Walls Up to 865mm High

Fill trench with road base and compact. Cover road base with approximately 25mm of sharp sand or crushed blue metal. Screed to a true level, starting from the lowest point if wall is stepping up.

For Walls Up to 1065mm High

Fill trench with concrete. Screed to a true level, starting from the lowest point if wall is stepping up. **TIP: Don't make the concrete mix too wet otherwise the blocks will sink into the mix.**

For Walls Over 1065mm High

Obtain Engineers specifications.

STEP 2 - LAYING FIRST COURSE

Place wall unit onto prepared base. It is essential that this first course of units is placed accurately to string line and levelled using a spirit level. For walls up to 1 metre high, make sure 100mm of the first block course is below the finished ground level.

STEP 3 - PLACING THE DRAIN

Place an agricultural drainage pipe with a geotextile sock (Ag-pipe) behind the first course of the wall on a bed of drainage material. Spread the drainage material such that the pipe has roughly a 1 in 100 fall (1cm drop over 1m length of wall).

Outlet the drain through the wall at every low point, at every 20 metres and around the ends of the wall, to your storm water system.

STEP 4 - PLACING ADDITIONAL COURSES

Clean debris from top of unit to ensure that the next unit will sit neatly. Place guide members in groove with pins facing upward and forward. It is important that all guide members are in place. Continue laying the subsequent courses following the same procedure as the first course. Place each course in running bond with course below (i.e. with the vertical joints from the first course units halfway along second course units) using locating pointer as a guide.

STEP 5 - BACKFILLING & COREFILLING

Fill all the cores of the blocks with 10-20mm clean, free drainage material (10-20mm gravel). Once all cores have been filled, place geo-textile fabric into place as per diagram on page 11 and back fill behind the wall using the same 10-20mm clean, free drainage material. Maintain high compaction rate on backfill material. Do not use soft or wet clay as backfill material.

For additional strength, No-Fines Concrete can be used to core fill and backfill the wall instead of the 10-20mm gravel.

STEP 6 - LAYING CAPPING UNITS

Once backfilling and cleaning is complete, place TrendStone® capping units in running bond, fixing them to top of wall using adhesive. For domestic wall installations, a waterproof construction adhesive is recommended. For high use areas, a 2-part epoxy is preferred.

STEP 7 - SURFACE DRAINAGE LAYER

Care should be taken where possible to divert water away from the face of the wall. If surface water cannot be naturally drained away from top of wall, place 100 - 150mm of clay impermeable layer (or similar) on top of back fill. If soil is used on top of this backfill, a layer of geo-textile fabric must be used to stop any soil filtering down through the drainage layer to back of wall.

Estimate Quantity Required

Rectangular areas

1. Measure the length (L) and width (W) of the area to be paved.
2. Multiply the L x W to work out the area (m²).
3. Multiply the area by the number of units in a m² (refer to product details).
4. Order up to 10% extra to allow for wastage such as cuts & breakages.

Triangular areas

1. Measure the base width (B) and length (L) of the triangular area to be paved.
2. Multiply the B x L and divide by 2 (B x L ÷ 2) to work out the area (m²).

Installation Guide

STEP 1 - PREPARE THE SITE

Prepare an area larger than the paved area required. Clear area of all vegetation, bark and soft soils. Check that finished height is not going to be higher than a nearby door opening.

STEP 2 - LAY A FOUNDATION

Lay certified road base and compact with a plate compactor. **For walkways:** Spread road base to a depth of 50mm to 80mm. **For driveways:** Spread road base around the entire area to a total depth of 150 to 200mm in 50mm layers, compacting between the layers. If laying on clay or fine sand use geo-fabric first.

STEP 3 - BEDDING SAND

Spread bedding sand evenly over the area to a depth of 40mm. Use a washed medium or coarse sand. Level and compact this bedding sand layer.

STEP 4 - SCREEDING BEDDING SAND

Start by placing a screeding board at one edge of the area to be paved (e.g. the base of a wall) to create a height reference mark. Lay the screeding board at 90° to the reference mark, to create level for the screeding rails. Allow for a slight fall away so that water will run off the pavers toward the lawn or garden. Lay the screed rails where you have just prepared, parallel to each other and a screeding board's distance apart. Place the screed on the rails and using a sawing motion pull the screed towards you. For large areas repeat this process.

STEP 5 - START PAVING


Set up a string line to suit the pattern you are going to lay and start laying along the longest straight edge of the area. Continue to lay pavers until the entire area is paved.

STEP 6 - EDGING

Remove all excess road base and sand from around the edge of the paved area. To keep pavers in a fixed position, an edge restraint must be installed. See diagram examples for two options.


EDGE RESTRAINT: EXAMPLE 1

Using the left-over sand, mix with cement at a 4:1 ratio. Smooth the concrete mix on an angle up against the edge of the paved area.



EDGE RESTRAINT: EXAMPLE 2

Remove the paving along the edge of the area and create a concrete beam approximately 100mm wide at the edge of the paved area. Sprinkle the beam with neat cement and lay the edge pavers on the beam. This will lock the pavers to the beam giving you a high-quality edge ideal for the garden or grass to grow up to.



STEP 7 - SWEEP IN THE SAND

Always use kiln dried sharp gap sand. Sweep the gap sand over the dry paving, ensuring that all the gaps are filled.

STEP 8 - PACK IT IN

For pavers with a thickness of 40mm the surface can be hand compacted with a piece of timber and a rubber mallet. Pavers with a thickness of 50mm or greater need to be compacted with a plate compactor. Always remember to use a rubber mat or carpet under the plate compactor to prevent damage to the pavers.

Pre-sealing admixtures are incorporated during the manufacture of these products. These admixtures significantly enhance waterproofing and assist in maintaining the appearance of your blocks and pavers for years to come. To ensure that your blocks and pavers are kept looking clean and fresh we recommend that you pay attention to the following instructions.

PAVERS

- Sweep frequently with a bristled broom to keep area free of debris.
- It is recommended sealing concrete pavers after installation. Sealing products recommended are from Shalex Industries - www.shalex.com.au
- If constructing in and around the paved area, cover the pavers to protect against damage.
- Protect your pavers against possible staining from mortar, oxides, cement and rust.
- Do not use acid to clean pavers.
- Avoid using high pressure cleaning apparatus to clean pavers.
- Joint maintenance - Any loss of sand in the joints must be promptly rectified. Repeat STEP 7 in 'PAVERS Installation Guide'.
- Control weeds by periodic applications of weedicide. Best results will be achieved in dry weather conditions.

Routine cleaning will keep your project in good condition, however should staining occur follow these simple steps:

- Identify type of stain carefully before taking action.
- Assess the efficacy of the cleaning compound or procedure by a trial on a small inconspicuous area of the pavement.
- Remove the worst stains first.
- Where abrasives, detergents or chemicals are used, ensure that all residues are immediately removed.
- Do not use acid to clean pavers.

IMPORTANT INFORMATION

Light coloured pavers emphasise tyre marks and oil spills on the driveway. It must be accepted that these products will need more maintenance if their overall appearance is to be maintained.

RETAINING WALLS

- If constructing in and around the area, cover the wall to protect against damage.
- Protect your retaining wall against possible staining from mortar, oxides, cement and rust.
- Do not use acid to clean retaining wall.

Routine cleaning will keep your project in good condition, however should mould growth occur follow these simple steps:


Initially try wet brush cleaning with warm water and household detergent or high pressure water blasting (ONLY use fan jet) with or without detergent. If other methods are unsuccessful, use ordinary bleach diluted down as per specifications then scrub with stiff brush. Make sure this area is flushed down with water.

NOTE: Test a small, inconspicuous area before cleaning the entire wall, to ensure solution doesn't damage wall.

EFFLORESCENCE

The most common cause of concrete product discolouration is efflorescence. It is a transitory occurrence and will usually disappear in time under abrasion by pedestrian and vehicular traffic and general weathering. Efflorescence does not affect the structural integrity or strength of the product. Efflorescence may be removed by stiff brush or the application of Anti-Eff (Environex International product) – Read suppliers instructions before use.

PROBLEM	SUGGESTED CLEANING METHOD
Efflorescence (White powdery deposit)	Use Environex Anti-EF or equivalent as per manufactures recommendation.
Leaves, bark, algae, food and wine stains	Use 10 parts water to 1 part bleach, then wash thoroughly down.
Chewing gum	Freeze with dry ice and remove with a spatula.
Ivy suckers	Apply a heat gun to the suckers until they go hard. Allow them to cool and dry, then scrub them off with a stiff bristled broom.





TrendStone® Charcoal & French LeMode Pattern Ivory

FREE PALLET COLLECTION

For free pallet collection service call **1300 781 620** or lodge a pick up online at **www.apexmasonry.com.au** or drop pallets back to place of purchase.



P 1300 781 620

F 07 4121 7170

E sales@apexmasonry.com.au

**17 Industrial Avenue
Maryborough Q 4650**

apexmasonry.com.au

TrendStone®, BoldStone™, LeMode®, Sierra®, Centro®, Classic Wall® and VividEdge™ are registered Trademarks.

COLOUR VARIATION

Colour samples are provided as an indication of the colours and textures available. Some variations in colour may occur due to natural changes within the raw material sources. When ordering your product, order all products of your project together to reduce the possibility of colour variation. We do not guarantee different batches will be the same colour.

EFFLORESCENCE

Efflorescence (a salty deposit) is a natural occurrence in masonry products. Efflorescence does not affect the structural integrity of the product and will usually diminish and disappear in the course of time as the product is exposed to the elements. No responsibility will be accepted for the occurrence of efflorescence.

CLAIMS

Claims must be reported within 72 hours of delivery. No claims will be accepted once product has been installed. Please contact the store where goods were purchased to report any concerns regarding product delivery or quality.

Minimum order quantities apply to Made to Order colours.